Preparing for a vertical blind survey

Photograph the window

Include the entire opening, any ceiling obstructions, door handles and where the stack will collect.

Approximate sizes

Provide width and drop in millimetres with the intended recess or face-fix position.

Controls

Note who will operate the blind, access requirements and whether power is available.

Special shapes

For slopes or non-standard shapes, a multi-stage measuring process may be necessary.

Survey and price

An initial remote estimate is free. On-site survey charges are confirmed before booking.