JOB REF.: JL			DATE:				Adan	nsBlin	ds® s	urvey	Form V9		
	LOCATION	BLIND TYPE	FABRIC / COLOUR NAME	WIDTH (mm)	DROP (mm)	MEASURE TYPE	CONTROL SIDE	INSTALL. HEIGHT	CEILING MATERIAL	INSTALLATION REQUIRES DRILLING INTO THE:			
No.	e.g.: Bedroom 1	e.g.: Vertical	e.g.: Deluxe White	e.g.: 1100	e.g.: 2200	R = Recess BS = Blind size FS = Fabric size	R = Right, L = Left RHC = Right H Control RHS = Right H Stack	From floor to the top of the blind e.g.: 220cm	P = PlasterC = ConcreteW = Wood	WINDOW / DOOR FRAME	CEILING /	OTHER (please specify	
1											/		
2										-	/		
3										-	√		
4											\		
5											√		
6											/		
7											√		
8										/	\		
9										-	/		
10										-	\checkmark		
<u>Notes</u> :										Estimated installation time:			
										For office use: YES NO			
Check for drawings and for extra notes overleaf!											e use: YE	SU NOU	
TO BE COMPLETED AND SIGNED BY THE CUSTOMERby the Fitterby the Customer													
1 - Removal of existing items (blinds, poles, curtains) to be done *£10 / item - *incl. VAT								* incl. VAT					
Disposal of existing items (blinds, poles, curtains) to be done *£10 / item - *incl. VAT								Customer Name					
After installation, disposal of all packaging materials to be done:													
	2 - The Customer confirms that the Surveyor has explained fitting including drillings as marked above										mar Sia	natura	
	 3 - The Customer confirms that blind type(s), fabric choices and control sides are correct on this measure sheet. 4 - The Customer confirms that by ordering any of these products or/and services, agrees to be bound by the Terms & Conditions. 										Customer Signature The tenant		
5 - Any special agreements:										The property owner			
										The contractor			
For the Terms & Conditions visit adamsblinds.co.uk/london/terms-and-conditions.php or email info@adamsblinds.co.uk for a copy.										Other			